

IMX6 Hummingboard - CAN bus


[imx6](#), [hummingboard](#), [carrierboard](#), [canbus](#), [can](#), [bus](#)

CAN Bus is only supported on Hummingboard Edge/Gate and MicroSom Rev. v1.4 and upper

Overview

A Controller Area Network (CAN bus) is a robust vehicle bus standard designed to allow microcontrollers and devices to communicate with each other in applications without a host computer. It is a message-based protocol, designed originally for multiplex electrical wiring within automobiles to save on copper, but is also used in many other contexts. (source wikipedia.com)

Hardware Modification



Notes

1. Requires MicroSOM rev 1.4 and newer
2. Requires Hummingboard Edge/Gate
3. Overlaps with HDMI connector CEC function. So only this or the HDMI connector can be assembled

In order to get the canbus up and running, following hardware modifications need to be done:

- Disassemble D5 and the HDMI connector
- Assemble:
 - R54
 - R53
 - C100
 - U10003 (CAN transceiver , for example TJA1050)
 - R55
 - L12
 - L13
 - C101
 - C102
 - L13
 - J28

per the HummingBoard2 schematics: [Hummingboard Documents](#)

Software Modification

Device Tree Changes

Edit following lines in the Device tree

- Disable HDMI-CEC by setting status = "disabled" - in [Github DeviceTree](#)
- Enable Flexcan1 in [Github DeviceTree](#)

(Re-)Compile DeviceTree

Generically speaking, the raw .dts files can be compiled into .dtb using the device-tree-compiler *dtc*. The most straightforward way to invoke it is by configuring the linux kernel tree, and then running

```
make dtbs
```

The kernel-tree needs to be configured first. Please refer to [IMX6 Kernel](#) for generic instructions, or consult the distro documentation

DTB files can also be de- and recompiled. Consult the manpage of *dtc* for additional information.

(Re-)Compile Linux Kernel

Either recompile linux kernel with config :

```
CONFIG_CAN=y  
CONFIG_CAN_RAW=y  
CONFIG_CAN_DEV=y  
CONFIG_CAN_FLEXCAN=y
```

or activate modules:

```
modprobe can  
modprobe flexcan  
modprobe can-dev  
modprobe can-raw
```

Test CanBUS

Enable device can0:

```
ip link set can0 up type can bitrate xxxxxx
```

(ex:125000)

Checking:

```
ip -details link show can0
```

The easiest way to test the CanBUS is to use the [CAN-Utills](#), which are available for Debain/Ubuntu etc.

Example commands:

Sending:

```
cansend can0
```

receiving:

```
candump can0
```

From:

<https://wiki.solid-run.com/> - Wiki | SolidRun

Permanent link:

<https://wiki.solid-run.com/doku.php?id=products:imx6:hummingboard:canbus>

Last update: **2017/12/14 19:59**

